

## Setting the moon dial

- Using an almanac or calendar, determine the date of the last full moon. Count the number of days past the last full moon.
- Apply slight pressure, using a glove or cloth, with your fingers to the front of the moon dial.
- Or preferably, open or remove the side panel and rotate the moon dial clockwise until the moon is directly below the #15.
- Turn the moon dial clockwise one click for every day past the full moon.
- If the moon dial does not move easily, the gears are engaged. Wait a few hours and then try moving it again.